







# **Areas of Application**

With more than 30 years experience in dealcoholization, the Schmidt® SIGMATEC has become the market leader worldwide. The experience gained in supplying a large number of dealcoholizing plants, our SIGMATEC design has become highly refined.

To date, SIGMATEC systems have been manufactured for a scope of capacity ranging from 2 h/l to 150 hl/h.

#### **Breweries**

Wheat beer, Pils, Pale Ale, Lager, Dunkel, Stout

#### Wineries

White/Red Wine, Sparkling Wine, Mulled Wine

#### Fruit/Cider Production

Perry, Cider

# **Other Industries**

Alcoholic Liquids, Extracts



# Advantages of the Procedure

- Dealcoholization under 0.05 vol-%
- Cost-Effectiveness
  - minimum volume loss
  - alcohol concentration to 75 80 vol-%, hence a valuable, marketable byproduct
  - fully automatic operation
  - low energy consumption
  - low maintenance cost

## Careful Handling of Product

- low processing temperature
- short holding time
- Environmentally Beneficial and Advantageous in the Conservation of Resources
- Optional Aroma Recovery
- Optional Dosing of Base Product
- Optional CIP System
- Optional Desulfurization of Grape Juice

# **Technical Versions**

# Materials and Specifications


# **Capacity Data**

Materials of Columns and Tanks:	All Current Stainless Steels	Feed Capacity:	2 HI/H - 150 HI/H (Beer)
Column Internals:	Metal Packings, Filling Material, Trays	Steam Consumption: Cooling Capacity:	15 - 18 Kg/HI 10 - 12 Kw/H
Column Diameters:	Dn 200 to Dn 2,000	Average Temperature:	40 - 80°C
Heating System:	Direct Steam or Hot Water	Alcohol Concentration at Inlet: Final Concentration of Alcohol:	0.75 - 15 Vol-% 40 - 85 Vol-%

















# **Technology**



Process Diagram for SIGMATEC Dealcoholization Plant

# **Description of Technical Procedure**

With SIGMATEC technology it is possible to dealcoholize a diverse range of alcoholic products. The process varies according to the nature of the given product and is based on the following criteria:

# Preheating

Using a Schmidt plate heat exchanger the medium is preheated to the required degassing temperature.

# Decarbonization

Depending on the final product, decarbonization takes place in a special vessel for the degassing procedure which enables mobile aromatic components to be recovered in the vacuum system.

# Vacuum Rectification

A high-capacity distillation column carefully removes the alcohol from the product.

# Flash Evaporation

From the already dealcoholized product a portion is evaporated in order to create the necessary stripping steam for the distillation tower.

#### Cooling

The medium is then cooled down by a Schmidt plate heat exchanger to approximately 2°C.

## Carbonization

On request it is possible to inject the product with CO<sub>2</sub>.

# Aroma Dosing

The aroma covered by an optional aroma recovery unit can be returned into the product. (Alternatively the product can be blended with the base product.)







# A world of heat transfer solutions

API Heat Transfer's global presence includes manufacturing facilities, R&D locations, and sales support throughout the world, all focused on one goal - to better serve our customers.





For more information about our heat transfer products, contact our API Heat Transfer sales representative or visit apiheattransfer.com or apiheattransfer.de

#### Germany

API Schmidt-Bretten GmbH & Co. KG

Langenmorgen 4 75015 Bretten Germany

+49 7252 530

#### USA

API Heat Transfer Inc.

2777 Walden Avenue Buffalo, NY, 14225 USA

+1 716 684 6700

#### China

API Heat Transfer Co., Ltd.

Meiheng Building 369 Wuzhong Road Minhang District Shanghai 201 103

PERFORMANCE IS EVERYTHING

+86 5426 2525

**GLOBAL HEADQUARTERS** 

2777 Walden Avenue | Buffalo, NY 14225 USA | +1.716.684.6700 | sales@apiheattransfer.com

Broschure\_Dealcoholization\_EN\_R7.indd 6 7/21/17 11:35 AM

apiheattransfer.com



